


Exploded view Zübat Pole Saw V.2015.06.10



Ref.	Article nr.	Description
1	KSI327133	blade Zübat 330
2	KZSI2720038	male clip scabbard
	KSI327011	male clip scabbard - old version (2015)
	KSI327012	female clip/washer
	KSI327004	screw cover
3	KZSI327251	scabbard set
4	KSI327003N	blade fixing pipe
	KSI327003	blade fixing pipe - old version (2007)
5-6-7	KSI310540	boltset
8	KZSI2720432	bolt (since 2012)
	KZSI36503	boltset (before 2012)
9	KZSI3700476	spring push button
	KZSI327002	spring push button - old version (2007)
10	KZSI327001	push button
11	KZSI3700477	spring fixing bolt

Ref.	Article nr.	Description
12	KZSI2340405	shaking-proof cover
13	KZSI327004	shaking-proof spacer
14	KZSI1770469	shaking-proof red lever
15	KZSI1770470	shaking-proof rod pin
16	KZSI3272129	shaking proof stopper set
17	KZSI2720402	rubber sleeve
18	KZSI2720403	rubber sole
19	KZSI2720404	rubber tape
	KZSI3272100	rubber handle - old version (2007)
20	KZSI3272121	upper pole Zübat 1200/2700
	KZSI3272151	upper pole Zübat 1500/3300
	KZSI3272181	upper pole Zübat 1800/3900
21	KZSI3272122	lower pole Zübat 1200/2700
	KZSI3272152	lower pole Zübat 1500/3300
	KZSI3272182	lower pole Zübat 1800/3900