


Akku-Grasschere ComfortCut Li
 Set Akku-Gras- und
 Strauchschere ComfortCut Li
 Set Akku-Grasschere ComfortCut Li

Art.-Nr. 9856

Art.-Nr. 9857

Art.-Nr. 9858




Akku-Grasschere ClassicCut Li
 Set Akku-Gras- und
 Strauchschere ClassicCut Li
 Set Akku-Grasschere ClassicCut Li

Art.-Nr. 9853

Art.-Nr. 9854

Art.-Nr. 9855



KES VAN DER SPEK
 TUINMACHINES * STOLWIJK

Bild Nr. Picture No.	Ersatzteil-Nr. Spare Part No.	Bezeichnung	Description	Désignation
Art. 9853		Akku-Grasschere ClassicCut Li	Grass Shear Accu ClassicCut Li	Cisaille à gazon ClassicCut Li
Art. 9854		Set Akku-Gras- und Strauchschere ClassicCut Li	Set Grass Shear Accu ClassicCut Li + Shurb Shears	Kit cisaille à gazon ClassicCut Li + lame taille-buissons
Art. 9855		Set Akku-Grasschere ClassicCut Li	Set Grass Shear Accu ClassicCut Li	Kit cisaille à gazon ClassicCut Li + manche télescopique + roues
1	9850-00.600.12	Schraube ST3x16 Torx	Screw ST3x16 Torx	Vis ST3x16 Torx
5	9853-00.640.00	Akku 3,6 V, 2,5 Ah	Accu 3,6 V, 2,5 Ah	Accu 3,6 V, 2,5 Ah
11	9853-00.620.00	Leiterplatte	Printed circuit card, cpl.	Circuit imprimé, cpl.
21	9853-00.630.02	Doppelrad	Twin gear wheel	Pignon double
24	9853-00.630.03	Zahnrad	Gear wheel	Pignon
26	9853-00.610.00	Messersatz vollst. (Art. 9862-20)	Blade set, cpl. (Art. 9862-20)	Jeu de lames, cpl. (Réf. 9862-20)
27	8885-00.610.01	Messerschutz	Blade protection	Protection de lame
28	9854-00.610.00	Messersatz vollst. (Art. 9863-20)	Blade set, cpl. (Art. 9863-20)	Jeu de lames, cpl. (Réf. 9863-20)
29	9854-00.611.04	Messerschutz	Blade protection	Protection de lame
30	9853-00.650.00	Steckerladegrät	Battery charger	Transformateur de charge
31	9861-00.600.00	Radsatz (Art. 9861-20)	Additional wheel (Art. 9861-20)	Roulettes de guidage (Réf. 9861-20)



Art. 9856		Akku-Grasschere ComfortCut Li	Grass Shear Accu ComfortCut Li	Cisaille à gazon ComfortCut Li
Art. 9857		Set Akku-Gras- und Strauchschere ComfortCut Li	Set Grass Shear Accu ComfortCut Li + Shurb Shears	Kit cisaille à gazon ClassicCut Li + lame taille-buissons
Art. 9858		Set Akku-Grasschere ComfortCut Li	Set Grass Shear Accu ComfortCut Li	Kit cisaille à gazon ComfortCut Li + manche télescopique + roues
1	9850-00.600.12	Schraube ST3x16 Torx	Screw ST3x16 Torx	Vis ST3x16 Torx
11	9856-00.640.00	Akku 3,6 V, 3,0 Ah	Accu 3,6 V, 3,0 Ah	Accu 3,6 V, 3,0 Ah
15	9853-00.620.00	Leiterplatte	Printed circuit card, cpl.	Circuit imprimé, cpl.
26	9853-00.630.02	Doppelrad	Twin gear wheel	Pignon double
29	9853-00.630.03	Zahnrad	Gear wheel	Pignon
31	9853-00.610.00	Messersatz vollst. (Art. 9862-20)	Blade set, cpl. (Art. 9862-20)	Jeu de lames, cpl. (Réf. 9862-20)
32	8885-00.610.01	Messerschutz	Blade protection	Protection de lame
33	9854-00.610.00	Messersatz vollst. (Art. 9863-20)	Blade set, cpl. (Art. 9863-20)	Jeu de lames, cpl. (Réf. 9863-20)
34	9854-00.611.04	Messerschutz	Blade protection	Protection de lame
35	9853-00.650.00	Steckerladegrät	Battery charger	Transformateur de charge
36	9861-00.600.00	Radsatz (Art. 9861-20)	Additional wheel (Art. 9861-20)	Roulettes de guidage (Réf. 9861-20)
		Nur die aufgeführten Teile sind lieferbar!	Only the mentioned spare parts are available!	Seules les pièces indiquées sont disponibles!