





# SPARE PARTS LIST

LAWN MOWERS: CONSUMER  
WALK-BEHINDS


LC 141i, 967628401, 2019-01




Referentie	Onderdeel nr	Omschrijving	Opmerking	Aant KIT al
1	587 58 50-01	WIELKAP		2
2	501 49 15-01	DEKSEL		2
3	587 91 35-01	BORGBOUT		4
4	587 91 29-01	LAGER		8
5	501 49 16-01	WIEL COMPL.		2
6	587 91 46-01	RING		4
7	579 68 46-01	BOUT		4
8	579 68 47-01	STEUN		2
9	579 68 48-01	VOORAS COMPL.		1
10	579 68 49-01	STEUN		2
11	587 91 31-01	BORGBOUT		8
12	587 58 51-01	WIELKAP		2
13	587 58 53-01	WIELKAP		2
14	587 91 80-01	WIEL		2
15	587 91 27-01	RING		2
16	579 68 50-01	ACHTERAS KOMPL.		1
17	587 58 57-01	KNOP		1
18	502 50 27-01	HANDGREEP COMPL.		1
19	587 91 26-01	SCREW		4
20	587 91 34-01	LOCK NUT		6
21	587 91 09-01	VASTZETPLAAT		2
22	587 99 24-01	VASTZETPLAAT		2
23	587 91 79-01	DEKSEL		2
24	579 68 51-01	BOUT		2
25	587 90 99-01	SEGMENT		1
26	579 68 52-01	MOER		2
27	579 68 54-01	DECK		1
28	587 91 58-01	TUBING		2
29	587 91 49-01	VEER		1
30	579 68 53-01	DRIJFSTANG		1
31	587 91 39-01	BOUT		4
32	579 68 81-01	BEVESTIGING		1
33	579 68 79-01	MOER		4
34	501 05 44-01	BEVESTIGING		1
35	502 23 10-01	STANG		1
36	587 91 51-01	VEER		1
37	587 91 50-01	BEVESTIGING		1
38	501 49 20-01	DEKSEL		1
39	579 68 55-01	SCREW		4
40	579 68 56-01	BEVESTIGING		1
41	579 68 57-01	PLAAT		1
42	579 68 94-01	MULCH KIT		1
43	579 85 70-01	PLUG		1 42
44	579 68 93-01	KNOOP		1 42
45	579 68 92-01	VEER		1 42
46	579 68 91-01	PLAAT		1 42
47	579 68 67-01	SCREW		2 42
48	579 85 69-01	MES		1 42



Referentie	Onderdeel nr	Omschrijving	Opmerking	Aant KIT al
1	587 58 63-01	GRASSBAG		1
2	587 91 18-01	BEVESTIGING		1
3	587 58 60-01	DEKSEL		1
4	587 91 23-01	SCREW		1
5	587 58 61-01	HENDEL		1
6	579 68 67-01	SCREW		2



Referentie	Onderdeel nr	Omschrijving	Opmerking	Aant KIT al
1	579 68 41-01	BOUT		1
2	579 68 42-01	VEERRING		1
3	579 68 43-01	RING		1
4	501 17 16-01	MOWER BLADE		1
5	579 68 45-01	MES HOUDER		1
6	579 68 58-01	MOER		4
7	579 68 59-01	HOUDER		1
8	579 68 60-01	RING		4
9	579 68 61-01	BOUT		4
10	579 68 62-01	MOTOR		1
11	579 68 63-01	SCREW		4
12	579 68 64-01	ELEKTRONISCHE KIST		1
13	579 68 65-01	RING		3
14	579 68 55-01	SCREW		16
15	579 68 66-02	KABEL		1
16	579 68 68-01	PLAAT		1
17	582 02 92-02	PRINTPLAAT COMPL.		1
18	579 68 69-01	SLEUTELSCHAKELAAR		1
19	501 48 96-01	DOOS		1
20	579 68 70-01	VEER		2
21	501 49 02-01	KAP		2
22	501 49 01-01	SLEUTEL		1
23	501 48 85-01	DEKSEL		1
24	501 48 87-01	DEKSEL		1
25	501 48 84-01	DEKSEL		1
26	579 68 67-01	SCREW		8
27	501 48 88-01	DEKSEL		1
28	579 68 71-01	AFDICHTING		1
29	501 48 83-01	DEKSEL		1
30	579 68 75-01	SCREW		12
31	501 48 95-01	DEKSEL		1
32	579 84 39-01	GEWICHT		1
33	579 68 76-01	RING		4
34	501 48 89-01	DEKSEL		1
35	501 48 91-01	STICKER		1
36	579 68 77-01	TORSIEVEER		1
37	501 48 98-01	SCHARNIER		2
38	579 68 78-01	TORSIEVEER		1





Referentie	Onderdeel nr	Omschrijving	Opmerking	Aant KIT al
1	589 96 93-01	HENDEL KIT		1
2	579 68 67-01	SCREW		1
3	579 68 75-01	SCREW		2
4	579 68 87-01	RING		2
5	579 68 65-01	RING		1
6	501 49 03-01	HOUDER		1
7	579 68 88-01	TORSIEVEER		1
8	501 49 04-01	DEKSEL		1
9	501 49 13-01	DEKSEL		1
10	502 42 99-01	BOUT		2
11	587 91 33-01	ZESKANT MOER		4
12	587 58 58-01	KNOP		4
13	579 68 80-01	STUUR		1
14	501 05 56-01	PLAAT		1
15	502 25 99-01	BOUT		2
16	502 25 87-01	AFSTANDRING		2
17	587 91 35-01	BORGBOUT		2
18	501 05 55-01	PLAAT		1
19	501 05 57-01	HOUDER		3
20	501 05 54-01	DEKSEL		2
21	502 40 21-01	BOUT		2