




**Akku-Grasschere ComfortCut Li** Art.-Nr. 9887  
**Set Akku-Gras- und Strauchschere ComfortCut Li** Art.-Nr. 9888  
**Set Akku-Grasschere ComfortCut Li** Art.-Nr. 9889



**Akku-Grasschere ClassicCut Li** Art.-Nr. 9884  
**Set Akku-Gras- und Strauchschere ClassicCut Li** Art.-Nr. 9885  
**Set Akku-Grasschere ClassicCut Li** Art.-Nr. 9886



**KEES VAN DER SPEK**  
 TUINMACHINES \* STOLWIJK

Bild Nr. Picture No.	Ersatzteil-Nr. Spare Part No.	Bezeichnung	Description	Désignation
<b>Art. 9884</b>		<b>Akku-Grasschere ClassicCut Li</b>	<b>Battery Grass Shears ClassicCut Li</b>	<b>Cisaille à gazon ClassicCut Li</b>
<b>Art. 9885</b>		<b>Set Akku-Gras- und Strauchschere ClassicCut Li</b>	<b>Battery Grass and Shrub Shears ClassicCut Li Set</b>	<b>Kit Cisaille à gazon ClassicCut Li + lame taille-buissons</b>
<b>Art. 9886</b>		<b>Set Akku-Grasschere ClassicCut Li</b>	<b>Battery Grass Shears ClassicCut Li Set</b>	<b>Kit Cisaille à gazon ClassicCut Li</b>
1	9850-00.600.12	Schraube ST3x16 Torx	Screw ST3x16 Torx	Vis ST3x16 Torx
5	9884-00.630.00	Akku 3,6 V, 2,5 Ah	Accu 3,6 V, 2,5 Ah	Accu 3,6 V, 2,5 Ah
11	9884-00.610.00	Leiterplatte	Printed circuit card	Circuit imprimé
21	9853-00.630.02	Doppelrad	Twin gear wheel	Pignon double
24	9853-00.630.03	Zahnrad	Gear wheel	Pignon
26	9853-00.610.00	Messersatz vollst. (Art. 9862-20)	Blade set, cpl. (Art. 9862-20)	Jeu de lames, cpl. (Réf. 9862-20)
27	8885-00.610.01	Messerschutz	Blade protection	Protection de lame
28	9854-00.610.00	Messersatz vollst. (Art. 9863-20)	Blade set, cpl. (Art. 9863-20)	Jeu de lames, cpl. (Réf. 9863-20)
29	9854-00.611.04	Messerschutz	Blade protection	Protection de lame
31	9861-00.600.00	Radsatz (Art. 9861-20)	Additional wheel (Art. 9861-20)	Roulettes de guidage (Réf. 9861-20)
	9884-00.600.06	USB-C Kabel	USB-C Cabel	USB-C Câble



<b>Art. 9887</b>		<b>Akku-Grasschere ComfortCut Li</b>	<b>Battery Grass Shears ComfortCut Li</b>	<b>Cisaille à gazon ComfortCut Li</b>
<b>Art. 9888</b>		<b>Set Akku-Gras- und Strauchschere ComfortCut Li</b>	<b>Battery Grass and Shrub Shears ComfortCut Li</b>	<b>Kit Cisaille à gazon ComfortCut Li + lame taille-buissons</b>
<b>Art. 9889</b>		<b>Set Akku-Grasschere ComfortCut Li</b>	<b>Battery Grass Shears ComfortCut Li Set</b>	<b>Kit Cisaille à gazon ComfortCut Li</b>
1	9850-00.600.12	Schraube ST3x16 Torx	Screw ST3x16 Torx	Vis ST3x16 Torx
5	9887-00.620.00	Akku 3,6 V, 3,0 Ah	Accu 3,6 V, 3,0 Ah	Accu 3,6 V, 3,0 Ah
11	9887-00.610.00	Leiterplatte	Printed circuit card	Circuit imprimé
21	9853-00.630.02	Doppelrad	Twin gear wheel	Pignon double
24	9853-00.630.03	Zahnrad	Gear wheel	Pignon
26	9853-00.610.00	Messersatz vollst. (Art. 9862-20)	Blade set, cpl. (Art. 9862-20)	Jeu de lames, cpl. (Réf. 9862-20)
27	8885-00.610.01	Messerschutz	Blade protection	Protection de lame
28	9854-00.610.00	Messersatz vollst. (Art. 9863-20)	Blade set, cpl. (Art. 9863-20)	Jeu de lames, cpl. (Réf. 9863-20)
29	9854-00.611.04	Messerschutz	Blade protection	Protection de lame
31	9861-00.600.00	Radsatz (Art. 9861-20)	Additional wheel (Art. 9861-20)	Roulettes de guidage (Réf. 9861-20)
	9884-00.600.06	USB-C Kabel	USB-C Cabel	USB-C Câble

Nur die aufgeführten Teile sind lieferbar!

Only the mentioned spare parts are available!

Seules les pièces indiquées sont disponibles!