




Akku-Grasschere ComfortCut Li Art.-Nr. 9887
Set Akku-Gras- und Strauchschere ComfortCut Li Art.-Nr. 9888
Set Akku-Grasschere ComfortCut Li Art.-Nr. 9889



Akku-Grasschere ClassicCut Li Art.-Nr. 9884
Set Akku-Gras- und Strauchschere ClassicCut Li Art.-Nr. 9885
Set Akku-Grasschere ClassicCut Li Art.-Nr. 9886



KEES VAN DER SPEK
 TUINMACHINES * STOLWIJK

Bild Nr. Picture No.	Ersatzteil-Nr. Spare Part No.	Bezeichnung	Description	Désignation
Art. 9884		Akku-Grasschere ClassicCut Li	Battery Grass Shears ClassicCut Li	Cisaille à gazon ClassicCut Li
Art. 9885		Set Akku-Gras- und Strauchschere ClassicCut Li	Battery Grass and Shrub Shears ClassicCut Li Set	Kit Cisaille à gazon ClassicCut Li + lame taille-buissons
Art. 9886		Set Akku-Grasschere ClassicCut Li	Battery Grass Shears ClassicCut Li Set	Kit Cisaille à gazon ClassicCut Li
1	9850-00.600.12	Schraube ST3x16 Torx	Screw ST3x16 Torx	Vis ST3x16 Torx
5	9884-00.630.00	Akku 3,6 V, 2,5 Ah	Accu 3,6 V, 2,5 Ah	Accu 3,6 V, 2,5 Ah
11	9884-00.610.00	Leiterplatte	Printed circuit card	Circuit imprimé
21	9853-00.630.02	Doppelrad	Twin gear wheel	Pignon double
24	9853-00.630.03	Zahnrad	Gear wheel	Pignon
26	9853-00.610.00	Messersatz vollst. (Art. 9862-20)	Blade set, cpl. (Art. 9862-20)	Jeu de lames, cpl. (Réf. 9862-20)
27	8885-00.610.01	Messerschutz	Blade protection	Protection de lame
28	9854-00.610.00	Messersatz vollst. (Art. 9863-20)	Blade set, cpl. (Art. 9863-20)	Jeu de lames, cpl. (Réf. 9863-20)
29	9854-00.611.04	Messerschutz	Blade protection	Protection de lame
31	9861-00.600.00	Radsatz (Art. 9861-20)	Additional wheel (Art. 9861-20)	Roulettes de guidage (Réf. 9861-20)
	9884-00.600.06	USB-C Kabel	USB-C Cabel	USB-C Câble



Art. 9887		Akku-Grasschere ComfortCut Li	Battery Grass Shears ComfortCut Li	Cisaille à gazon ComfortCut Li
Art. 9888		Set Akku-Gras- und Strauchschere ComfortCut Li	Battery Grass and Shrub Shears ComfortCut Li	Kit Cisaille à gazon ComfortCut Li + lame taille-buissons
Art. 9889		Set Akku-Grasschere ComfortCut Li	Battery Grass Shears ComfortCut Li Set	Kit Cisaille à gazon ComfortCut Li
1	9850-00.600.12	Schraube ST3x16 Torx	Screw ST3x16 Torx	Vis ST3x16 Torx
5	9887-00.620.00	Akku 3,6 V, 3,0 Ah	Accu 3,6 V, 3,0 Ah	Accu 3,6 V, 3,0 Ah
11	9887-00.610.00	Leiterplatte	Printed circuit card	Circuit imprimé
21	9853-00.630.02	Doppelrad	Twin gear wheel	Pignon double
24	9853-00.630.03	Zahnrad	Gear wheel	Pignon
26	9853-00.610.00	Messersatz vollst. (Art. 9862-20)	Blade set, cpl. (Art. 9862-20)	Jeu de lames, cpl. (Réf. 9862-20)
27	8885-00.610.01	Messerschutz	Blade protection	Protection de lame
28	9854-00.610.00	Messersatz vollst. (Art. 9863-20)	Blade set, cpl. (Art. 9863-20)	Jeu de lames, cpl. (Réf. 9863-20)
29	9854-00.611.04	Messerschutz	Blade protection	Protection de lame
31	9861-00.600.00	Radsatz (Art. 9861-20)	Additional wheel (Art. 9861-20)	Roulettes de guidage (Réf. 9861-20)
	9884-00.600.06	USB-C Kabel	USB-C Cabel	USB-C Câble

Nur die aufgeführten Teile sind lieferbar!

Only the mentioned spare parts are available!

Seules les pièces indiquées sont disponibles!